



External Snap Ring

Dimensions

1/16 in	1/8 in	3/16 in	1/4 in	3/8 in
1/2 in	5/8 in	3/4 in	7/8 in	

DESCRIPTION

An external snap ring fits into the grooves of a shaft to secure parts and hold components of an assembly. Open these rings, pass them over the end of a shaft, and release to spring into the groove, ideally using a retaining ring plier tool.

AVAILABLE PRODUCTS

Product #	Dimensions
ESR116MR	1/16 in
ESR18MR	1/8 in
ESR18WMR	1/8 in
ESR316MR	3/16 in
ESR316WMR	3/16 in
ESR14MR	1/4 in
ESR14WMR	1/4 in
ESR38MR	3/8 in
ESR38WMR	3/8 in
ESR12MR	1/2 in
ESR12WMR	1/2 in
ESR58MR	5/8 in
ESR34MR	3/4 in
ESR78MR	7/8 in

TECHNICAL SPECIFICATIONS

Material	Black
Brand	Reliable

PRODUCT PHOTOS

